

TOCON starter kit

optional accessory



▶ PROPERTIES OF THE TOCON STARTER KIT

- kit for initial testing setup - take a standard voltmeter from your toolbox and get into the world of UV radiometry
- output voltage 0 ... 5 V
- usable with all TOCON detectors (not included)
- 9 V block battery included, typical runtime 3000 hours
- separate 4 mm banana plug ground and signal cable for easy connection

▶ HOW TO CONNECT

- put a TOCON into the 3 pin transistor socket
- connect the 9 V battery
- put the 4 mm banana plug connectors into your voltmeter

yellow = signal voltage out = plus terminal of the voltmeter

black = ground = ground terminal of the voltmeter